

UNISEAL- Hole Sizing Chart	
Pipe Size	Hole Saw Size Needed
1/2"	1-1/4"
3/4"	1-1/4"
1"	1-3/4"
1-1/4"	2"
1-1/2"	2-1/2"
2"	3"
3"	4"
4"	5"

Instructions

- 1-Cut hole with holesaw to the size indicated.
- 2-Ensure that the hole is cut clean. Irregular holes could cause poor seating and possible leaks.
- 3-Insert the uniseal with the wide surface facing out.
- 4-Make certain the pipe to be inserted is cut clean and square, file or sand the edges so there are no rough or sharp edges to cut the uniseal surface.
- 5-Use liquid soap or teflon lube on the pipe to be inserted. Insert the pipe into the uniseal as far as needed to clear the inside of the seal by about 1".